




# QUANTUM ELECTRONICS

For atomic physics

# REVIEW

## Gaussian Beam



$$\nabla_t^2 \psi - 2ik \frac{\partial \psi}{\partial z} = 0,$$

$$\psi(x, y, z) = \exp \left\{ -i \left( P(z) + \frac{k}{2q(z)} r^2 \right) \right\}$$



complex beam parameter  $q$

$$\frac{1}{q} = \frac{1}{R} - i \frac{\lambda}{n\pi\omega^2}$$

$$\omega(z) = \omega_0 \left[ 1 + \left( \frac{\lambda z}{n\pi\omega_0^2} \right)^2 \right]^{1/2}$$

$$R(z) = z \left[ 1 + \left( \frac{n\pi\omega_0^2}{\lambda z} \right)^2 \right].$$

Gaussian intensity profile



$$q(z) = q_0 + z = i \frac{n\pi\omega_0^2}{\lambda} + z$$


$$\frac{1}{q} = \frac{1}{R} - i \frac{\lambda}{n\pi\omega^2}$$

Distance to waist  $= -\text{Re}\{q(z)\}$  and,

$$\text{Radius of waist} = \sqrt{\frac{\lambda}{n\pi} \text{Im}\{q(z)\}}.$$

$$\omega(z) = \omega_0 \left[ 1 + \left( \frac{\lambda z}{n\pi\omega_0^2} \right)^2 \right]^{1/2}$$

$$R(z) = z \left[ 1 + \left( \frac{n\pi\omega_0^2}{\lambda z} \right)^2 \right].$$



$$\text{Rayleigh length} \equiv z_R = \frac{n\pi\omega_0^2}{\lambda}$$


$$\text{Confocal parameter} \equiv b = \frac{2n\pi\omega_0^2}{\lambda}.$$

$$q = z + i \frac{n\pi\omega_0^2}{\lambda}$$

$$= z + iz_R$$

$$\omega(z) = \omega_0 \left[ 1 + \left( \frac{z}{z_R} \right)^2 \right]^{1/2}$$

$$R(z) = z + \frac{z_R^2}{z}.$$



Distance to waist:  $z = -\frac{Re\{q_1\}}{|q_1|^2} \quad \left( q_1 \equiv \frac{1}{q} \right)$

Rayleigh length:  $z_R = -\frac{Im\{q_1\}}{|q_1|^2}$

Waist size:  $\omega_0^2 = \left( \frac{\lambda}{n\pi} \right) z_R = - \left( \frac{\lambda}{n\pi} \right) \frac{Im\{q_1\}}{|q_1|^2}$

Spot size:  $\omega^2 = -\frac{\lambda}{n\pi Im\{q_1\}}.$

$$\omega_0 = \frac{\lambda R \omega}{\sqrt{(\pi n \omega^2)^2 + (\lambda R)^2}}$$

# 1.5 THE PHASE TERM: GOUY PHASE


$$\psi(x, y, z) = \exp \left\{ -i \left( P(z) + \frac{k}{2q(z)} r^2 \right) \right\}$$

$$\frac{dP(z)}{dz} = -\frac{i}{q(z)} = -\frac{i}{z + i(n\pi\omega_0^2/\lambda)}.$$

$$iP(z) = \ln[1 - i(\lambda z/n\pi\omega_0^2)] = \ln \sqrt{1 + \left( \frac{\lambda z}{n\pi\omega_0^2} \right)^2} - i \tan^{-1} \left( \frac{\lambda z}{n\pi\omega_0^2} \right)$$

$$u(x, y, z) = \psi(x, y, z)e^{-ikz}$$

$$u = \frac{1}{\sqrt{1 + \left( \frac{z}{z_R} \right)^2}} \exp \left\{ i \tan^{-1} \left( \frac{z}{z_R} \right) - ik \left( z + \frac{r^2}{2R} \right) - \frac{r^2}{\omega^2} \right\}$$



$$u = \frac{1}{\sqrt{1 + \left(\frac{z}{z_R}\right)^2}} \exp \left\{ i \tan^{-1} \left( \frac{z}{z_R} \right) - ik \left( z + \frac{r^2}{2R} \right) - \frac{r^2}{\omega^2} \right\}$$


$$\text{Phase shift of Gaussian beam} = i\phi = \underbrace{ikz}_{\text{normal}} - \underbrace{i \tan^{-1} \frac{z}{z_R}}_{\text{Gouy}}$$

# 1.6 SIMPLE TRANSFORMATION PROPERTIES OF THE COMPLEX BEAM PARAMETER

Free space

$$q(z_2) = q(z_1) + z_2 - z_1$$

Thin Lens



$$\frac{1}{q} = \frac{1}{R} - i \frac{\lambda}{n\pi\omega^2}$$


$$\frac{1}{i} + \frac{1}{o} = \frac{1}{f} \longrightarrow \frac{1}{R_1} - \frac{1}{R_2} = \frac{1}{f}$$

$$\text{Since } \omega_1 = \omega_2, \quad \frac{1}{q_1} - \frac{1}{q_2} = \frac{1}{f} \longrightarrow q_2 = \frac{q_1}{1 - q_1/f}$$




# RULES FOR SIGN

- We are taking the frame along the propagation direction of the light.
- Positive  $f$  of a lens ( $R$  of a mirror) is related to the real image.
- Negative  $f$  of a lens ( $R$  of a mirror) is related to the virtual image.
- $R$  of Gaussian beam is different from the radius of curvature of optics.



# RULES FOR SIGN

- We are taking the frame along the propagation direction of the light.
- Positive  $f$  of a lens ( $R$  of a mirror) is related to the real image.
- Negative  $f$  of a lens ( $R$  of a mirror) is related to the virtual image.
- $R$  of Gaussian beam is different from the radius of curvature of optics.



# RULES FOR SIGN

- We are taking the frame along the propagation direction of the light.
- Positive  $f$  of a lens ( $R$  of a mirror) is related to the real image.
- Negative  $f$  of a lens ( $R$  of a mirror) is related to the virtual image.
- $R$  of Gaussian beam is different from the radius of curvature of optics.




plano-convex

$$R_1 > 0$$
$$R_2 = \infty$$



biconvex

$$R_1 > 0$$
$$R_2 < 0$$



biconcave

$$R_1 < 0$$
$$R_2 > 0$$



meniscus

$$R_1 < 0$$
$$R_2 < 0$$

## Thin Spherical Mirror

$$q_2 = \frac{q_1}{1 - 2q_2/R}$$

Since,  $f = R/2$

Slap of thickness,  $d$ , and index,  $n$

At the interface,

$$q_1 = nq_0$$

The internal travel,


$$q_2 = q_1 + d$$

At the other interface,

$$q_3 = \frac{1}{n}q_2$$

The total

$$q_3 = q_0 + \frac{d}{n}$$



Case	$q$ -transformation	Ray matrix
Free-space	$q_1 = q_0 + d = \frac{(1)q_0 + (d)}{(0)q_0 + (1)}$	$\begin{pmatrix} 1 & d \\ 0 & 1 \end{pmatrix}$
Thin lens	$q_1 = \frac{q_0}{1 - q_0/f} = \frac{(1)q_0 + (0)}{(-1/f)q_0 + (1)}$	$\begin{pmatrix} 1 & 0 \\ -1/f & 1 \end{pmatrix}$
Mirror	$q_1 = \frac{q_0}{1 - 2q_0/R} = \frac{(1)q_0 + (0)}{(-2/R)q_0 + (1)}$	$\begin{pmatrix} 1 & 0 \\ -2/R & 1 \end{pmatrix}$
Slab	$q_1 = q_0 + d/n = \frac{(1)q_0 + (d/n)}{(0)q_1 + (1)}$	$\begin{pmatrix} 1 & d/n \\ 0 & 1 \end{pmatrix}$

# 1.7 MATRIX FORMULATION OF PARAXIAL RAY OPTICS: ABCD RULE

Ray vector:  $\begin{pmatrix} y \\ y' \end{pmatrix}$  Height  $y$ ,  
Slope  $y'$

$$q_1 = \frac{Aq_0 + B}{Cq_0 + D} \iff \begin{pmatrix} A & B \\ C & D \end{pmatrix}$$

# COMPOUND OPTICS – ABCD MATRIX

- The ray tracing technique is based on two reference planes, called the input and output planes, each perpendicular to the optical axis of the system.
- A light ray enters the system when the ray crosses the input plane at a distance  $y_1$  from the optical axis while traveling in a direction that makes an angle  $y'_1$  with the optical axis.
- Some distance further along, the ray crosses the output plane, this time at a distance  $y_2$  from the optical axis and making an angle  $y'_2$ .  
, where  $y'_1, y'_2 \ll 1$


$$\begin{pmatrix} y_2 \\ y'_2 \end{pmatrix} = \begin{pmatrix} A & B \\ C & D \end{pmatrix} \begin{pmatrix} y_1 \\ y'_1 \end{pmatrix}$$

# ABCD MATRIX – SPACE

$$\begin{pmatrix} y2 \\ y'2 \end{pmatrix} = \begin{pmatrix} A & B \\ C & D \end{pmatrix} \begin{pmatrix} y1 \\ y'1 \end{pmatrix}$$

- $y2 = y1 + d y'1$
- $y'2 = y'1$

$$\therefore \begin{pmatrix} A & B \\ C & D \end{pmatrix} = \begin{pmatrix} 1 & d \\ 0 & 1 \end{pmatrix}$$






# ABCD MATRIX – INTERFACE


$$\begin{pmatrix} y_2 \\ y'_2 \end{pmatrix} = \begin{pmatrix} A & B \\ C & D \end{pmatrix} \begin{pmatrix} y_1 \\ y'_1 \end{pmatrix}$$

- $y_2 = y_1$
- $n_2 y'_2 = n_1 y'_1$

$$\therefore \begin{pmatrix} A & B \\ C & D \end{pmatrix} = \begin{pmatrix} 1 & 0 \\ 0 & n_1/n_2 \end{pmatrix}$$



# ABCD MATRIX – CURVED INTERFACE



- $y_2 = y_1$
- $y'_2 = \frac{n_1 - n_2}{R n_2} y_1 + \frac{n_1}{n_2} y'_1$

$$\therefore \begin{pmatrix} A & B \\ C & D \end{pmatrix} = \begin{pmatrix} 1 & 0 \\ \frac{n_1 - n_2}{R n_2} & n_1/n_2 \end{pmatrix}$$

Element	Matrix	Remarks
Propagation in free space or in a medium of constant refractive index	$\begin{pmatrix} 1 & d \\ 0 & 1 \end{pmatrix}$	$d = \text{distance}$
Refraction at a flat interface	$\begin{pmatrix} 1 & 0 \\ 0 & \frac{n_1}{n_2} \end{pmatrix}$	$n_1 = \text{initial refractive index}$ $n_2 = \text{final refractive index}$
Refraction at a curved interface	$\begin{pmatrix} 1 & 0 \\ \frac{n_1 - n_2}{R \cdot n_2} & \frac{n_1}{n_2} \end{pmatrix}$	$R = \text{radius of curvature, } R > \text{ for convex (centre of curvature after interface)}$ $n_1 = \text{initial refractive index}$ $n_2 = \text{final refractive index}$
Reflection from a flat mirror	$\begin{pmatrix} 1 & 0 \\ 0 & 1 \end{pmatrix}$	Identity matrix
Reflection from a curved mirror	$\begin{pmatrix} 1 & 0 \\ -\frac{2}{R} & 1 \end{pmatrix}$	$R = \text{radius of curvature, } R > 0 \text{ for convex}$
Thin lens	$\begin{pmatrix} 1 & 0 \\ -\frac{1}{f} & 1 \end{pmatrix}$	$f = \text{focal length of lens where } f > 0 \text{ for convex/positive (converging) lens. Valid if and only if the focal length is}$

**Homework: derive ABCD matrix for a curved mirror, a thin lens and a thick lens**

$$q_1 = \frac{Aq_0 + B}{Cq_0 + D} \iff \begin{pmatrix} A & B \\ C & D \end{pmatrix}$$

Case	$q$ -transformation	Ray matrix
Free-space	$q_1 = q_0 + d = \frac{(1)q_0 + (d)}{(0)q_0 + (1)}$	$\begin{pmatrix} 1 & d \\ 0 & 1 \end{pmatrix}$
Thin lens	$q_1 = \frac{q_0}{1 - q_0/f} = \frac{(1)q_0 + (0)}{(-1/f)q_0 + (1)}$	$\begin{pmatrix} 1 & 0 \\ -1/f & 1 \end{pmatrix}$
Mirror	$q_1 = \frac{q_0}{1 - 2q_0/R} = \frac{(1)q_0 + (0)}{(-2/R)q_0 + (1)}$	$\begin{pmatrix} 1 & 0 \\ -2/R & 1 \end{pmatrix}$
Slab	$q_1 = q_0 + d/n = \frac{(1)q_0 + (d/n)}{(0)q_1 + (1)}$	$\begin{pmatrix} 1 & d/n \\ 0 & 1 \end{pmatrix}$


**ABCD rule:** The overall q-transformation for a complex system composed of thin lenses, thin mirrors, free spaces and slabs can be obtained by determining the ABCD matrices of the individual components, multiplying the matrices together and applying to the composite matrix.

$$q_0 \xrightarrow{ABCD} q_1 \xrightarrow{A'B'C'D'} q_2$$

$$q_0 \longrightarrow q_1 : \begin{pmatrix} A & B \\ C & D \end{pmatrix} \quad q_1 \longrightarrow q_2 : \begin{pmatrix} A' & B' \\ C' & D' \end{pmatrix}$$

$$q_2 = \frac{A'q_1 + B'}{C'q_1 + D'} = \frac{(A'A + B'C)q_0 + (A'B + B'D)}{(C'A + D'C)q_0 + (C'B + D'D)}$$

# GAUSSIAN BEAM PROPAGATION



**Homework:** By using ABCD matrix, find the q-parameters after passing through the lens with focal length  $f$  depending on  $d$ . Find the new beam waist  $w_0'$  and the distance to it. When  $z_R \gg f$ , find the  $w_0'$  and distance to it in terms of  $f$ ,  $w_0$ , and  $\lambda$ .

# PROPER USAGE OF PLANO-CONVEX LENS




Figure 2.9: Spread in focal length for plano-convex lens with the two possible orientations. For the left orientation the spread of the focal points are larger than for the one to the right.

**Homework: Show that one of them give smaller beam waist.**